



System Requirement

USB Programmer #500804U

Application: PN Racing 500804C V4 Programmable Servo Board

Operating Voltage: USB (5V/500mA)


Software Download <https://pnracing.com/download/PN-V2105.exe> or

<https://pnracing.com/download/PN-V2105.rar>

Operating System: Windows XP/Windows Vista/Windows 7/Windows 8/Windows 20 32/64bit)

Software Menu Instruction

Display Window will display connection status as well as servo parameter writing and reading status



Parameter Function Information

1. Servo Angle: Set the servo rotation angle
2. Servo Neutral: Set the servo neutral position

Note: Set transmitter at neutral position, modify this value to adjust the servo horn to desired position.

3. PWM Power: Adjust the servo output power. The higher the power, the higher the servo torque and speed, current consumption will be high as well.
4. Damping Factor: Set the servo damping.
5. Sensitivity: Adjust the servo dead band (sensitivity).
6. Soft Start: Slowly restoration while power on the servo. Once power on, the servo will gently turn to the position of current input signal.

Note: This function is to prevent damage in case the servo is mounted incorrectly.

7. Inversion: Set normal and reverse rotation of the servo.
8. Narrow Band: FUTABA SR Mode
9. SANWA SSR: SANWA SSR Mode

Note: Enable this function to support SANWA SSR high speed mode. Servo angle needs to re-adjust.

10. Lost PPM Protect: Signal loss protection, there are three functions for selection,
 - a. Release: Non-Protection
 - b. Keep Position: Stay in the position before the signal loss
 - c. Go Neutral Position: Back to Neutral position (1500uS position)
11. Over Load Protect: Set the servo blocking protection, there are 3 levels, Check the box to enable protection.

Note: The value on the left indicates when servo protection will turn on, the value on the right indicates max power output when servo protection is turned on.

12. Servo Information: Servo information. Including servo model, version date, firmware name.
13. Read: Read the servo parameter from the software interface.
14. Write: Write current parameter into servo.
15. Open: Open servo parameter file which saved on the computer.
16. Save: Save current servo parameter to the computer

17. UPF: Servo firmware upgrade function.
18. Default: Restore factory default setting.
19. Exit: Exit and close the configuration software

Parameter Function Instruction

1. PWM Power: Adjust the servo output power. The higher the power, the higher the servo torque and speed, current consumption will be high as well.
2. Inversion: Set normal and reverse rotation of the servo
3. Servo Information: Servo information. Including servo model, version date, firmware name.
Servo Name: Servo model
Manufacture: Servo version date
Firmware: Servo firmware name
4. Read: Read the servo parameter from the software interface.
5. Write: Write current parameter into servo.
6. Open: Open servo parameter file which saved on the computer.
7. Save: Save current servo parameter to the computer
8. UPF: Servo firmware upgrade function.
9. Default: Restore factory defaults
10. Exit: Exit and close the configuration software

Default Setting

After long time testing by PN team, we find out the best setting for the PNR2.5 and MR03 chassis.